


C	2, 1	6	4, 3	5	8, 7	10, 49, 11	2, 3	4	5	6	7	8	9	10, 11, 12	9	13, 16	15	17, 14, 18	31, 19	20, 21, 22, 23, 24, 12, 50, 25, 29	38, 26, 30	32	33, 48, 27	37	28, 47, 36	34, 35, 46, 43, 42, 41, 39, 40	23, 22, 24, 26, 19	25	45, 44																
L	1, 2, 3, 4	20	21, 22, 23, 24, 7, 6, 5, 6	7	8	9	10, 11, 12	9	13, 14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50



ECH4 AZ1

ECH4

EM4

EBL1


POLOHY SPOJENÉ DOTEKY P10-P14

I	21-22, 29-30
II	21-22, 27-28, 29-30
III	23-24, 27-28
IV	23-24, 27-28, 25-26

ROZSAHY SPOJENÉ DOTEKY P1-P9

KV	4-5, 10-11, 14-15, 18-19
SV	3-5, 6-7, 8-9, 12-13, 16-17, 18-19
DV	2-5, 18-19
Q	1-5, 19-20

NAPĚTÍ A PROUDY PŘI NORMÁLNÍM PROVOZU
(SĚPNUTÝ SPÍNAČE SPORIČE P15, P16)



PATICE ELEKTRONEK