



R	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100
C	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100
L	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100



VOLIČ WSILAČU P7, P8

VLNĚVÉ PÁSMO	SPOJENÍ DOTYK P7	SPOJENÍ DOTYK P8
1 195-353m	2-6, 8-12	2-6, 8-12
2 333-577m	2-5, 8-11	2-5, 8-11
PLNĚNĚ LADĚNÍ	2-4, 8-10	2-4, 8-10
3 1000-1600m	2-3, 8-9	2-3, 8-9



PŘEPÍNAČ ROZSAHŮ P1-P6

ROZSAH	SPOJENÉ DOTYKY P1	SPOJENÉ DOTYKY P2	SPOJENÉ DOTYKY P3	SPOJENÉ DOTYKY P4	SPOJENÉ DOTYKY P5	SPOJENÉ DOTYKY P6
KV1	4-10	2-6	2-6-12	7-8-9	2-3-10	6-7-8
KV2	5-10	3-6	2-5-11	7-8-9	2-4-10	6-7-8
SV	6-10	1-2-3	4-6-10-11	2-4-10	6-7-8	1-12-9-5
DV	7-10	1-2-3	5-6-11-12	2-3-9	2-6-12	6-7-8
OSTANÍ	11-1	8-10	1-2-3-6	2-8	8-9-1	1-5
OMIKRO	12-1	9-10	2-3-6	—	9-1	—

PŘEPÍNAČ PŘEDNESU P9

POLOHA	SPOJENÉ DOTYKY P9
REC	2-3-4-5-8
ŠIROKÉ P.	2-3-4-5-8
STŘEDNÍ P.	12-2-3-4-8
ÚZKÉ P.	11-12-2-3-8
REC-HUDBA	10-11-12-2-8

